

STARKE *ARVID*

User Manual

Waste Bin Tipping Frame



Dear Customer!

Thank you for choosing a Starke Arvid® product.
We have over 40 years of experience in the construction industry. We develop, manufacture, and sell professional-grade equipment for material handling.
The Starke Arvid product range includes more than 20 products.
Visit: www.starkearvid.se


General Maintenance and Care Instructions:

- Daily checks
 - Ensure the rotation locks move freely.
 - Inspect fork pockets for any damage.
- Monthly checks
 - Lubricate all moving parts.
 - Check that all four rubber dampers are intact.
- Annual checks:
 - Inspect all moving parts, welds, and structural components.
 - Remove any surface rust and touch up the paint.
 - Replace worn parts.
 - If in doubt, contact Starke Arvid AB.

Usage / Safety Instructions:

- To mount the Waste Bin Tipping Frame, insert the forklift forks into the fork pockets. Tilt upward to slide the tipping frame fully onto the forks until it locks into position.
- Make sure the forks are fully inserted and in the “locked” position.
- When using forks with a large rear radius, a safety chain or strap must be used.
- A safety chain or strap must also be used if tilting the forks more than 20 degrees.
- To lift a wastebin, drive the tipping frame under the bin and lift it slowly. Ensure the bin’s axle fits into the tipping frame’s cutout.
- Transport the bin to the desired dumping location. During transport, the tipping frame should not be more than approx. 1 meter above ground level.
- Empty the bin by tilting the forks downward until the wastebin tips forward and empties.
- Do not shake the frame. The locking of the axle occurs automatically during the tilting motion.

Spare Parts



Spare Parts		
Pos.	Waste Bin Tipping Frame	78000
1	Rotation lock, complete, left <i>(from driver)</i>	78001R
2	Rotation lock, complete, right <i>(from driver)</i>	78002R
3	Damper 40x15 <i>(smaller at the front)</i>	78003R
4	Damper 70x20 <i>(larger on the fork pocket)</i>	78004R



Sorting and emptying the wastebins is easy with the Waste Bin Tipping Frame. Tilt the machine's lifting forks, and the tipping frame gently tips forward to empty the contents.



Sorting and emptying the wastebins is made easy with the Waste Bin Tipping Frame. Tilt the machine's forks, and the tipping frame tilts forward to empty the contents.



Easy waste disposal thanks to the smooth emptying of the wastebins using the Waste Bin Tipping Frame.

Technical Specifications

Article number:	78000
Max load:	1000 kg
Width:	610 mm
Length:	1470 mm
Height:	180 mm
Weight:	58 kg
Fork pocket dimensions:	150 mm x 70 mm
(Optional fork pockets):	190 mm x 90 mm (on request)
Max fork length:	1200 mm

More detailed technical data and user instructions are available at <http://www.starkearvid.com> - Phone: +46 522-22 000